

BT30 Nose Index

Shrink Fit	PAGE 56
SX Collet Chuck	PAGE 57
MX Collet Chuck	PAGE 58
VX Collet Chuck	PAGE 58
HC Hydraulic Chuck	PAGE 59
MC Mill Chuck	PAGE 59
ER Collet Chuck	PAGE 60
End Mill Adapters	PAGE 61
Shell Mill	PAGE 62
QC Tapping	PAGE 63
Drill Chucks	PAGE 64
Test / Runout Bars	PAGE 65

CAT40

CAT50

BT 30

BT40

HSK 40E

HSK 63A

HSK 100A

STRAIGHT
SHANKS

COLLETS

PARTS &
ACCESS.

SHRINK
MACHINES

INDEXERS

