

Wrenches



Hex

For Torque Values see page 164

Nut Size	Metric	Type	Works On	Part Number Open End	Part Number Box End	Drive	Torque Wrench Head #
0.50	12.7	Hex (Open End)	DA300	WRENCH DAW300			
0.67	17.0	Hex (Open End)	ER11H	WRENCH ERW-11 HEX	WRENCH ERW-11 H-R	0.375	TWSQ037-H17
0.71	18.0	Hex (Open End)	SXN06	WRENCH SXW-06 H		0.375	TWSQ037-H18
0.75	19.0	Hex (Open End)	DA200	WRENCH DAW200			
0.94	24.0	Hex (Open End)	DA100	WRENCH DAW100			
0.98	25.0	Hex (Open End)	ER16H	WRENCH ERW-16 HEX	WRENCH ERW-16 H-R	0.500	TWSQ050-H254
1.00	25.4	Hex (Open End)	SXN10	WRENCH SXW-10 H		0.500	TWSQ050-H254
1.18	30.0	Hex (Open End)	ER20H	WRENCH ERW-20 HEX	WRENCH ERW-20 H-R	0.500	TWSQ050-H30
1.26	32.0	Hex (Open End)	DA180, ER32H-EXT	WRENCH DAW180			TWSQ050-H318



E Type

For Torque Values see page 164

Nut Size	Metric	Type	Works On	Part Number Open End	Part Number Box End	Drive	Torque Wrench Head #
1.26	32.0	E Type	ERN16	WRENCH ERW-16 E	WRENCH ERW-16 E-R	0.500	TWSQ050-S32
1.38	35.0	E Type	ERN20	WRENCH ERW-20 E	WRENCH ERW-20 E-R	0.500	TWSQ050-S38
1.65	42.0	E Type	ERN25	WRENCH ERW-25 E	WRENCH ERW-25 E-R	0.500	TWSQ050-ER25E
1.97	50.0	E Type	ERN32	WRENCH ERW-32 E	WRENCH ERW-32 E-R	0.500	TWSQ050-ER32E
2.48	63.0	E Type	ERN40	WRENCH ERW-40 E	WRENCH ERW-40 E-R	0.500	TWSQ050-ER40E



Mini E Type

For Torque Values see page 164

Nut Size	Metric	Type	Works On	Part Number
0.47	12.0	Mini E	ER08	WRENCH ERW- 8M
0.63	16.0	Mini E	SX06M, ER11M	WRENCH ERW-11 M
0.87	22.1	Mini E	SX10M, ER16M	WRENCH ERW-16 M
1.10	28.0	Mini E	ER20M	WRENCH ERW-20 M

